

A beautiful green lawn is just a spray away with **Evergreen Spray & Feed Lawn Food Gun!** The lawn quickly absorbs the feed to give a richer greener colour that lasts up to 6 weeks. It helps lawns recover from wear and tear and is ideal for lawns used by children and pets.

DIRECTIONS FOR USE

WHEN TO USE:

Use anytime between March and September. Repeat after 6 weeks. Avoid using during frosty or hot conditions.



COVERAGE:

This pack treats 100 square metres (i.e. 10 metres by 10 metres) and it sprays most lawns in 12 minutes.



SPRAYING INSTRUCTIONS

STEP 1 Preparation



Shake well before use. Connect sprayer to hose and turn on water. To begin spraying, point nozzle in the direction you want to spray.



1 Bend small green plastic tab on side of sprayer back and 2 turn knob clockwise to ON position.

STEP 2 Spraying



Spray evenly over measured area. To stop spraying, bend small green plastic tab back and turn knob anti-clockwise to OFF position. Turn off water. To relieve water pressure still in the hose bend the plastic tab back and turn knob to ON position until water slows to a drip. Then turn knob to OFF position.

To comply with Water Supply Regulations, we recommend using a double check valve.

*Under normal growing conditions

NPK FERTILISER 27-0-1 with IRON

Nitrogen (N) total 27.0%

Ureic nitrogen (N) 13.5%

Potassium Oxide (K₂O) 1.0% (0.8% K)
soluble in water

Iron (Fe) soluble in water 0.5%

Store between 0°C and 30°C

@/™ Trade Marks of The Scotts Company or its affiliates.

The Scotts Company (UK) Ltd,
Catteshall Lane, Godalming,
Surrey GU7 1XE

1 litre e

for more information visit

lovethegarden.com

or call 0845 190 1881

FOR FURTHER ADVICE or a Free Guide to a Better Lawn, contact the Scotts Garden Advisor on 0870 5301010.

Online product labels are current at the time of uploading.
Always read the label on your purchased product before use.