

Instructions for use

Refer to your product pack for guidance on the amount of product to apply.

To fill, place the spreader on a level surface. Do not fill directly on a lawn or cultivated area.

Adjust the setting of the spreader using the slider on the right-hand side of the trigger.

To apply, hold the spreader at a comfortable height, pull the trigger and walk normally whilst turning the handle.

Application rates can vary depending on crank and walking speed. To increase application rate, overlap more frequently.

Brush up any spilt product. Clean spreader after use.

Spreader Settings

- 4** **Scotts® Lawn Builder range of fertilisers**
Moderate fertiliser coverage*
- 5** **EverGreen® range of fertilisers**
Heavy fertiliser coverage**

*For application rates of 20g/m². Overlap the treated area twice.

**For application rates of 30 - 35g/m². Overlap the treated area three times.

© 2008, Evergreen Garden Care UK Ltd,
1 Archipelago, Lyon Way, Frimley,
Surrey GU16 7ER.

For more information visit:

evergreen-lawn.co.uk
or call **+44 (0)1276 401 300**